


LC300 Main Fuel Tank(110L)



Material: Al-Mg Alloy







Tank Capacity: 110L

- **Website:** shop.fkoffroad.com
- **Email:** support@fkoffroad.com
- **Phone:** +86 177 0115 5098 (Whatsapp available)
- **Address:** No.3 Tongda Road, Dongmaquan Town, Wuqing District, Tianjin, China

For technical support or additional product information, please contact our customer service team.





LC300 Main Fuel Tank Parts List

NO.	Part Name Part No.	Illustration	QTY
1	Main Fuel Tank Main Body		1
	25F3823-01		
2	Fuel Tank Rollover Vent Valve		1
	25T-A		
3	Middle Strap		1
	25F3807-02		
4	Rear Strap		1
	25F3807-03		
5	Middle Strap Bracket		1
	25F3802-04		
6	Rear Strap Bracket		1
	25F3802-05		
7	Vapor Canister Vent Hose		1
	25G3823-C		
8	Main Tank Vent Hose		1
	25G3823-B		

LC300 Main Fuel Tank Parts List

Installation Hardware Kit:

Illustration	Specification	Qty	Unit
Stainless Steel Button Head Hex Socket Screw: 	6mm x 8mm	4	Pcs
Bolt: 	8mmx25mm	5	pcs
	10mm x 30mm(fine thread)	2	pcs
	10mm x 30mm	3	pcs
Nut: 	8mm	4	pcs
Nut Tab: 	10mm	1	pc
Washer: 	8mm x 22mm	5	pcs
	10mm x 22mm	5	pcs
Hardware Part Number:25F3823-06			

Assembly Parts Kit:

Fuel Pump Housing O-Ring Seal(Spare): 	OD 145mm x Wire Dia. 5mm	1	pc
Vent Valve O-Ring Seal: 	OD 90mm x Wire Dia. 3mm	1	pc
Canister Vent Hose Clamp 	Ø15mm	1	pc
Heavy Duty Screw-Mount Cable Tie: 	M6	4	Pcs

- **Website:** shop.fkoffroad.com
- **Email:** support@fkoffroad.com
- **Phone:** +86 177 0115 5098 (Whatsapp available)
- **Address:** No.3 Tongda Road, Dongmaquan Town, Wuqing District, Tianjin, China

For technical support or additional product information, please contact our customer service team.

